



How to set the local time zone


To set the local time zone, you will need to press the button that is on the right hand side of the Smart Reader Data Logger, (next to the SD Card slot) by using a sharp object like a pin, needle or similar.

The sequence starts with Eastern Standard Time.

Every click will move the time zone in this sequence to the West:

1. Eastern Standard Time (EST) Toronto
2. Central Standard Time (CST) Winnipeg
3. Mountain Standard Time (MST) Edmonton
4. Pacific Standard Time (PST) Vancouver
5. Newfoundland Standard Time (NST) St. John's
6. Atlantic Standard Time (AST) Halifax
7. The next click will set EST again.

The Smart Reader Data Logger is set to account for the Daylight saving time and changes automatically to Winter and Summer time,



Smart Reader Data Logger

2010 Winston Park Drive, Suite 200,

Oakville, ON, L6H 5R7

Email: info@smartreader.ca

Phone: (416) 524-5445

www.smartreader.ca

